



ECOS INTERIOR WALL PRIMER APPLICATION INSTRUCTIONS

| | |
|---------------------------------|---|
| Recommended For | Use on standard gypsum drywall and plaster surfaces as a smooth and clean bonding finish prior to painting with a topcoat |
| Coverage | 400 sq. ft. per gallon 100 sq. ft. per quart; 1 coat recommended |
| Description | Drywall Primer is used to provide a strong bonding layer that gives standard gypsum drywall and plaster surfaces a smooth and clean finish before painting with an ECOS Paints topcoat. Suitable for interior uses. |
| Preparation | Surfaces should be clean, dry, sound, and free from dirt, dust, grease, and loose or flaking material. Especially important is the removal of any dust created from sanding. Use a damp cloth/sponge to remove dust, a vacuum or dry cloth/sponge can be insufficient. Areas of joint compound, or mud, must be thoroughly cleaned as any remaining dust can cause flaking, or peeling. Soft, or crumbly, substrates must be pre-treated before priming. |
| Application and Clean Up | Under most conditions thinning is not necessary. Stir gently before and during use. Generally, only requires one coat. Normally dries to the touch in four hours. Allow twenty-four hours before sanding or painting. Can be applied using a high quality synthetic brush, rolled using a tightly woven, shed-resistant 3/8" to 1/2" roller cover, or sprayed using an airless sprayer with 0.015" to 0.017" tip at 1600 to 1800 psi. Avoid applying below 50°F (10°C). |